

1 servo description

1.1. servo driver mode

company name **Samkoon®**

Type **MODEL: R8-2208P-N**

power supply **INPUT: 1Ph AC 200-240V 50/60Hz**


output data **OUTPUT: 3Ph AC 0-240V 5.5A 0.8kW**

S/N: **S/N:**

Shen Zhen Samkoon Technology Corporation Ltd.

R8 - 22 - 08 - P -

Identification	Power voltage	Output Power	communication type	non-standard code
22	single-phase 220V	02 220W	P	standard
38	three-phase 380V	04 400W	Z	non-standard
		08 800W		
		10 1000W		
		15 1500W		



1.2. Motor Type

Company name **Samkoon®**

mode **MODEL: 80HK-A00630**

power mode **AC 220V 1.3A 200W**

Rated Speed **3000 0.64N·m**

rated torque


Waterproof **IP65**

S/N: **S/N:**

80 HK - A 024 30 - CS□□2


Identification	Flange size mm×mm	Identification	encoder type	Identification	torque N·m	Identification	speed rpm	Identification	encoder
60	60×60	A	Absolute type17bit	013	1.3	20	2000	C	magnetic encoder
80	80×80	B	Absolute type23bit	024	2.4	30	3000	L	light encoder
110	110×110							S	Single-tap encoder
								M	Multi-tap encoder
								2	Lock motor
								3	Lock motor

2 Servo installation




- * install in cabinet and free of the Sun and rain
- * Do not expose to flammable gases
- * do not install in high temperature (>45°C), humid (>90% Rh), there are dust, metal dust.
- * Please ensure that the installation direction should vertical to wall, use natural wind or fan to cool the drive, when many servo drives are installed side by side, please install according to the distance requirement
- * Please ground the terminal PE, otherwise there may be electric shock or interference caused by the risk of servo error action
- * please do not immediately remove the drive or motor after power off in case of electric shock or scalding
- * Please wait for 5 minutes before operating (please make sure the CHARGE light on the servo panel is turned off)

3 Servo wiring



S/N	Name	Description
1	Circuit breaker	Cut-off circuit when power supply overflows
2	Circuit filter	install circuit filter to prevent noise from outside power supply
3	Contactor	servo power on/off please install current surge suppressor
4	Brake Resistance	When capacitance is insufficient, P-C terminal should connect external brake resistance
5	Lock motor power	24VDC voltage, when the servo motor is equipped with a brake
6	Contactor	Brake Control Signal, turn brake power on or off, when in use please install current surge suppressor, recommended use of servo DO control Contactor
7	Control Cable	non-standard, provide terminals, cable should be made by yourself or purchased separately
8	encoder cable	please choose a suitable length of cable
9	power cable	

Control Terminal CN1 signal rules




Control Terminal CN1 signal definition

function	Terminal mark	name	Definition
pulse input	35	PS_24V	PLC power DC24V
	43	PULS-	pulse input signal/differential pulse input negative
	41	PULS+	differential pulse input negative positive
	39	SIGN-	Input 1(default function: servo enable)
input and output	37	SIGN+	differential pulse input negative positive
	9	DI1	Input 1(default function: servo enable)
	10	DI2	Input 2(default function: alarm reset)
	34	DI3	Input 3(default function: positive overrun)
analog	8	DI4	Input 4(default function: negative overrun)
	11	COM	Input Public Terminal
	1	DO1+	Output 1(default function: servo ready)
	16	DO1-	Output 1(default function: arrived position)
Frequency division output	3	DO2+	Output 2(default function: lock gate output)
	2	DO2-	Output 2(default function: lock gate output)
	5	DO3+	Output 3(default function: failure output)
	4	DO3-	Output 3(default function: failure output)
RS485	7	DO4+	Output 4(default function: failure output)
	6	DO4-	Output 4(default function: failure output)
	32	AI1+	analog input Channel1,-10v ~ +10V (can be used as speed and torque instruction)
	17	AI1-	analog input Channel1,-10v ~ +10V (can be used as speed and torque instruction)
RS485	18	AI2+	Analog Input Channel2,-10V ~ +10V (can be used as speed and torque instruction)
	19	AI2-	Analog Input Channel2,-10V ~ +10V (can be used as speed and torque instruction)
	25	PAO+	differential output (5V level) (signal source can be chosen as encoder or pulse)
	24	PAO-	differential output (5V level) (signal source can be chosen as encoder or pulse)
RS485	22	PBO+	differential output (5V level) (signal source can be chosen as encoder or pulse)
	23	PBO-	differential output (5V level) (signal source can be chosen as encoder or pulse)
	20	PCO+	differential output (5V level) (signal source can be chosen as encoder or pulse)
	21	PCO-	differential output (5V level) (signal source can be chosen as encoder or pulse)
RS485	44	OZ	Single-terminal Z pulse output
	29	GND	Driver digital ground
RS485	12	485/A	Modbus Communication
	14	485/B	Modbus Communication


Strong electricity terminal rules

Terminal number	Name	Description
L1	power input	if connected to single-phase AC 220V, connected between L1 and L2, let L3 empty, do not connect
L2		
L3		
P	Brake Resistance Terminal	when using internal brake resistance, connect P and D, when using external brake resistor, please disconnect P and D, do it between P and C.
D		
C		
N	DC power main line negative	The DC power main line terminals of the servo are P and N, which can be connected to main line when multiple machines
U		Motor cables
V		
W		
PE		


Servo IO terminals and PLC connection




brake connection




R8 series AC power servo driver



single-terminal pulse input wiring




differential pulse input wiring (differential or external 5V power supply)




4 Panel display and operation

4.1. panel




Name	Description
Digital Tube	5-digit digital tube
Mode	mode/return key, switch menu/return to the previous
▲	Up Flip Key, menu flip/value +1
▼	down Flip Key, menu flippers/value -1
◀▶	shift, set values when shift operation:
Set	set, confirm

4.2. menu structure




4.3. Parameter reset and JOG operation



5 Position mode wiring and operation

5.1. Wiring



The DI/DO terminal functions of CN1 can be configured by parameters. The default functions listed in this figure can be changed according to specific requirements. In practice, it may not be necessary to use these input and output points in the system, and they may not be connected

5.2. Parameter settings

After confirming the wiring, according to the actual usage, set the basic parameters according to the parameter sequence in the following table

Parameter number	name	frist value	Parameter Description
C-000	Operation mode	0	set to position operation mode. For other operation modes, please refer to the "R8 series servo manual"
C-004	pulse form	0	Set the actual output pulse to the following values [0] Pulse+direction [2] CW+CCW [1] AB phase, 4 times harmonic [3] AB phase
C-005	pulses one cycle	10000	Set the number of pulse commands required for the motor rotate one cycle. If ask for Electric wheel ratio, please set the value to 0
C-006	Electric wheel ratio molecular1	1	It takes effect when the value of "C-005 single cycle pulse count" is 0, Displacement=The instruction displacement unit is the motor encoder counting unit
C-007	Electric wheel ratio molecular1	1	
C-003	DI1 terminal logic selection	0	In the default configuration, "P04-DI1 terminal function selection" is set to "1] Servo enable". When the external DI input is not used to control the servo enable, the parameter could be used to set the servo enable. When set to 1, the servo enable, and when set to 0, the servo disable. When using external DI input to control servo enable, please configure the input enable logic correctly

5.3. Status monitoring

During the operation process, the servo operation status can be confirmed through the following parameters

Parameter number	name	unit	Parameter Description
O-000	Servo operation status	-	During normal operation, the value is 2. For other values, follow the following formula for troubleshooting: [0] Please check if the power supply voltage input is normal [1] Check if the servo enable signal input is correct [3] Refer to "9.3 Alarm solve" for troubleshooting issues
O-001	alarming id	-	When the value is not 0, refer to "9.3 Alarm solve" to troubleshoot the problem
O-002	Motor speed	rpm	Check the current motor running speed
O-003	Speed command	rpm	Speed command given in servo operation
O-004	Torque command	%	Torque command given in servo operation
O-005	Torque feedback	%	Actual output torque during servo operation
O-010	pulse count	ins	Count the pulses only after the servo is enabled
O-012	Input pulse count	ins	Count input pulses even if the servo is not enabled
O-014	Feedback pulse count	p	It is 0 after restarting, and start count after motor rotation